


## FITTING SERVICE DOG VEST



Threads together at chest



Buckles together under belly



Thread strap through buckle and adjust to fit

Clip buckles together and adjust to fit



Clip the male/female clips together. Take the remaining two straps and thread them through the buckle. Adjust this to slip over the dog's head; unclip the rear buckles and clip under the dog's belly, adjusting as you go.

The front strap should fit across the dog's chest with the vest laying flat like a saddle.